


RVP Placement instructions



6.2.7 Requesting Placement

When you are requesting placement for multiple cars, you can request that your railroad place:

- All cars on a single track with no spot specified
- All cars ordered on a single track - specifying the first spot
- All cars on a unique track and in a unique spot
- All cars on a unique track with no spot specified

To request placement at your facility:

Step	Action
1	Locate and select the car(s) to request placement.
2	Click  The Action Panel displays.
3	Click  , and then select Place from the menu. The Place view displays.
4	Review the selected car(s)s (de-select any that you do not want Placed)

Step	Action	
5	To...	Do this...
	Specify a single track for all cars...	Select the Track Drop-down at the top of the form and select a track. 
	Specify a starting spot for all cars on a single track or instructing to place on any available spot on the track.	After specifying a single track, click in the  field and type in the spot number for the first car, and then tab out of spot field. RVP autofills each car's spot in ascending order. OR – to instruct to place on any available spot – type SP, and tab out. RVP autofills SP to each cars spot field.
	Specify unique tracks for each car...	Select the Track Drop-down NEXT to each car and specify a track. 
	Specify unique spots for each car... (Optional)	Type in a spot number next to each car. 
6	Click Apply. The Request Placement confirmation dialog displays.	
7	Click Confirm. A success message displays. A success message displays. If so configured, a work order may automatically be created for your railroad. As always, ensure that you have communicated with your railroad so that the communication process is clear.	